


AlphaEclipse™ 3500 Series B Sign Service Manual

This manual only applies to “Series B” AlphaEclipse 3500 signs.

LED boards

See “1.2 How LED rows are numbered in this manual” on page 8.



Manual part number: 9711-6019

Revision date: September 12, 2003



ADAPTIVE®

© Copyright 2001, 2002, 2003 Adaptive Micro Systems, Inc. All rights reserved.

Trademarked names appear throughout this document. Rather than list the names and entities that own the trademarks or insert a trademark symbol with each mention of the trademarked name, the publisher states that it is using names for editorial purposes and to the benefit of the trademark owner with no intention of improperly using the trademark.

The following are trademarks of Adaptive Micro Systems: ActiveX, Adaptive, Alpha, AlphaLert, AlphaNET, AlphaNet plus, AlphaEclipse, AlphaPremiere, AlphaTicker, AlphaVision, AlphaVision InfoTracker, Automode, BetaBrite, BetaBrite Director, BetaBrite Messaging Software, Big Dot, Director, EZ KEY II, EZ95, PagerNET, PPD, PrintPak, Serial Clock, Smart Alec, Solar, TimeNet.

The distinctive trade dress of this product is a trademark claimed by Adaptive Micro Systems, Inc.

Due to continuing product innovation, specifications in this manual are subject to change without notice.

Contents

1.0	Notes	7
1.1	How to tell a Series A from a Series B sign	7
1.2	How LED rows are numbered in this manual	8
2.0	Introduction.....	9
2.1	Purpose	9
2.2	Revision history	9
2.3	Related documentation	9
2.4	Controlling electrostatic discharge (ESD)	10
2.5	Safety information.....	10
2.5.1	Equipment symbols	10
2.5.2	Warnings and cautions	11
2.5.3	Battery backup	11
3.0	Equipment description	13
3.1	Overview	13
3.2	Technical specifications	14
3.2.1	Outside view	14
3.2.2	Inside view.....	15
3.2.3	Physical and electrical specifications	19
3.3	Equipment identification	20
3.4	EMI compliance	20
3.5	Temperature protection.....	21
3.6	Optional equipment.....	22
3.6.1	Temperature probe option	22
3.6.2	Modem option	22
3.6.3	Wireless transceiver option.....	24
3.6.4	Fiber optic modem option	25
4.0	Installation	27
4.1	Mechanical installation.....	27
4.1.1	Designing the support structure	27
4.1.2	Lifting the sign.....	27
4.1.3	Mounting the sign.....	28

4.1.4	Mounting a temperature probe	29
4.2	Electrical installation	30
4.2.1	Guidelines for electrical installation	30
4.2.2	Opening the sign	31
4.2.3	Installing signal wiring	34
4.2.4	Connecting power to the sign	34
4.2.5	Closing the sign	35
4.3	Installation checkout test	36
5.0	Networking signs	37
5.1	Series A and B sign networking comparison.....	37
5.2	Computer-to-sign connection methods	38
5.2.1	External connection box (RS232) computer-to-sign connection	39
5.2.2	External connection box (RS485) computer-to-sign connection	40
5.2.3	Converter Box III (RS485) computer-to-sign connection.....	41
5.2.4	Fiber optic computer-to-sign connection	42
5.2.5	Ethernet computer-to-sign connection	43
5.2.6	Modem computer-to-sign connection.....	44
5.2.7	Wireless computer-to-sign connection	45
5.3	Sign-to-sign connection methods.....	46
5.3.1	Master/Master sign-to-sign connection	47
5.3.2	Master/Slave sign-to-sign connection.....	48
5.4	Termination.....	49
5.4.1	Termination DIP switches	49
5.4.2	Termination examples.....	49
6.0	Basic operating instructions	51
6.1	Basic setup for AlphaNET software	51
6.1.1	Create a device.....	51
6.1.2	Create a site	54
6.1.3	Create and send a message	56
6.2	Setting the time and date on a sign.....	56
6.3	Setting the dimming time for a sign.....	57
7.0	Maintenance	59
8.0	Troubleshooting	61
8.1	Common sign problems.....	61
8.1.1	Problem: Pattern of blocks and diagonal bars keep repeating	62

8.1.2	Problem: Letter “B”s fill the sign.....	63
8.1.3	Problem: Temperature or “ERR” appears in upper right	64
8.1.4	Problem: Temperature is inaccurate	65
8.1.5	Problem: Temperature displayed on two signs is inaccurate	66
8.1.6	Problem: All LEDs are on	67
8.1.7	Problem: No LEDs are on.....	68
8.1.8	Problem: Startup message keeps reappearing	69
8.1.9	Problem: Text and graphics appear dim	70
8.1.10	Problem: Only two LEDs in upper left are on	71
8.1.11	Problem: Text appears scrambled.....	72
8.1.12	Problem: Messages sent from AlphaNET software do not appear	73
8.1.13	Problem: Graphics sent from AlphaNET software do not appear	74
8.1.14	Problem: One or more LED boards is off	75
8.1.15	Problem: Entire row of LED boards is off.....	76
8.1.16	Problem: Entire section of sign is off	77
8.2	Troubleshooting procedures	78
8.2.1	PC-TO-SIGN CHECK procedure.....	79
8.2.2	PC FEEDBACK procedure	81
8.2.3	ALPHANET MESSAGE procedure.....	82
8.2.4	PC CHECK procedure	84
8.2.5	SIGN RESTART procedure.....	96
8.2.6	TEST MODES procedure	97
8.2.7	SIGN FEEDBACK procedure	99
8.2.8	SIGN POWER procedure.....	101
8.2.9	SIGN CHECK procedure	104
8.2.10	OUTSIDE INSPECTION procedure.....	112
8.2.11	INSIDE INSPECTION procedure.....	113
8.2.12	TEMP PROBE CHECK procedure.....	114
8.2.13	TEMP PROBE FIX procedure.....	115
8.2.14	PC DIP SWITCH procedure.....	116
8.2.15	SIGN DIP SWITCH procedure	117
8.2.16	OVERHEAT CHECK procedure.....	118
8.2.17	OVERHEAT FIX procedure.....	119
8.3	Controller board DIP switches	120
8.3.1	Bank 1 and Bank 2 DIP switches.....	121
8.3.2	Bank 3 DIP switches	122
8.4	AlphaNET Diagnostics software	123
8.4.1	Startup screen	123
8.4.2	Configure Sign (Advanced) screen.....	125
9.0	Parts replacement	127
9.1	List of field-replaceable parts	127

9.2	Controlling electrostatic discharge (ESD)	127
9.3	Controller board	128
9.3.1	Controller board description	128
9.3.2	Controller board replacement	130
9.4	Turbo extender board replacement	131
9.5	Fan replacement.....	132
9.5.1	Exhaust fan replacement.....	132
9.5.2	Power supply fan replacement.....	134
9.6	LED board replacement.....	135
9.7	Power supply replacement.....	137
9.7.1	Power supply description	137
9.7.2	Power supply replacement.....	138
9.8	Firmware upgrade	140

1.0 Notes

1.1 How to tell a Series A from a Series B sign


Use an AlphaEclipse 3500 sign’s identification label to determine if the sign is a Series A or B. The identification label is located on the back of the sign’s case and on the inside of the sign.

Table 1: Series A and Series B sign identification labels


Series A label:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
 (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
 (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE D OPERATION.

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.
 Cet appareil numérique de la class A respecte toutes les exigences du Reglement sur le materiel brouilleur du Canada.



CERTIFIED TO
CAN/CSA STD.
C22.2 No. 950
CONFORMS TO
ANSI/UL STD.
No. 1950



PARTS SERVICEABLE BY TRAINED TECHNICIANS ONLY!
DISCONNECT POWER BEFORE SERVICING

NEMA TYPE 3R

ADAPTIVE
Adaptive Micro Systems Inc

A


MODEL NO: **3500 — 64x16 — A**
 VOLTS: **120 VAC ~**
 Hz: **50/60 Hz**
 AMPS: **7.41 A**

DATE OF MANUFACTURE: 8/8/2001
 SERIAL NO: **DT0002313**


Series B label:

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS:
 (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE.
 (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE D OPERATION.

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.
 Cet appareil numérique de la class A respecte toutes les exigences du Reglement sur le materiel brouilleur du Canada.



CERTIFIED TO CSA STD.
C22.2 No. 60950-00-CAN/CSA
CONFORMS TO UL STD.
No. 60950 3RD EDITION



PARTS SERVICEABLE BY TRAINED TECHNICIANS ONLY!
DISCONNECT POWER BEFORE SERVICING

TYPE 3R ENCLOSURE

ADAPTIVE
Adaptive Micro Systems Inc
Milwaukee, Wisconsin 53224 USA

A

MODEL NO: **3500 — 64X16 — A**
 SERIES: **B**
 VOLTS: **120 VAC ~**
 Hz: **50/60 Hz**
 AMPS: **7.41 A**

DATE OF MANUFACTURE: 8/15/2002
 SERIAL NO: **DT0002208**

B


Item	Name	Description
A	Model number	<div style="text-align: center;"> <p>3500 — 64x16 — A</p> <div style="display: flex; justify-content: center; gap: 20px;"> <div style="text-align: center;"> <p>LED lamp viewing angle:</p> <ul style="list-style-type: none"> • 00 = 30 degree • 01 = 70 degree </div> <div style="text-align: center;"> <p>Width (pixel columns)</p> <p>Height (pixel rows)</p> </div> <div style="text-align: center;"> <p>LED lamp color:</p> <ul style="list-style-type: none"> • A = Amber • R = Red </div> </div> <p>1.4" pitch, 4 led lamps per pixel</p> </div>
B	Series letter	Indicates a basic design revision (only appears on the Series B label)

1.2 How LED rows are numbered in this manual

LED board rows are numbered as if the sign was open and you were looking at the *backs* of the LED boards. Below is an example of how the LED board rows in a 2-line sign would be numbered:

LED ROW 2

LED ROW 1



2.0 Introduction

2.1 Purpose

This manual is intended as a guide for maintenance and repairs considered field serviceable.

This field service manual supplies technical information for service and technical personnel so that they can maintain the equipment at the assembly but not the component level.

2.2 Revision history

Table 2: Revision history

Revision	Date	Notes
9711-6019	September 12, 2003	First preliminary release

2.3 Related documentation

Technical documentation can be found at Adaptive's web site.

Table 3: Related documentation

Part #	Manual title	Description
Manuals (http://www.adaptivedisplays.com/manuals/)		
9711-6009B	AlphaEclipse 3500 Series A Service Manual	The service manual for only Series A AlphaEclipse 3500 signs.
9708-8081G	AlphaNET 3.0 User Manual	Describes the software used to send messages to an AlphaEclipse sign
9711-6015	AlphaEclipse 3500 Series B Sign Installation Manual	Provides electrical, mechanical, and network installation instructions for the most current version of the AlphaEclipse Series B sign.
9700-0130	Creating Graphics for AlphaEclipse Signs	Explains how to use create simple graphics for AlphaEclipse 2500, 2600, and 3500 signs.
TechMemos (http://www.adaptivedisplays.com/ams/dtechmemo.htm)		
03-0002	AlphaEclipse 3500 Series A and B Sign Wireless Transceiver Install Instructions	How to install a 120V Locus wireless transceiver on an AlphaEclipse 3500 Series A or B sign.
02-0006	Cleaning AlphaEclipse 1500, 2500, 2600, and 3500 Outdoor Signs	Instructions for hand-cleaning the exterior of an AlphaEclipse sign.
02-0003	AlphaEclipse 3500 Sign Firmware and FPGA Chip Upgrade	Explains: <ul style="list-style-type: none"> the changes in the new firmware (Main 1162-5001E, Peripheral 1162-4001D) and FPGA chip (version 1.2, 2611-1621) how to upgrade a sign.

Table 3: Related documentation

Part #	Manual title	Description
02-0002	Cable Replacement for AlphaEclipse 3500 Signs	How to clean, protect, and attach cables to AlphaEclipse 3500 Series A signs.
01-0012	Using the T3000 Tool to Remove Ribbon Cables	How to use the T3000 tool to remove ribbon cables from an AlphaEclipse 3500 Series A sign's LED boards.
01-0010	Upgrading Firmware on AlphaEclipse 3500 Series Signs	How to use the Alpha Flash Updater software to upgrade the firmware on an AlphaEclipse 3500 sign.
01-0009	AlphaEclipse 3500 Back-to-Back Sign RS422 (Master/Slave) to RS485 Modification Instructions	How to convert two AlphaEclipse 3500 Series A signs from Master/Slave to Master/Master networking.
01-0006	Replacing the Turbo Extender Board on an AlphaEclipse Controller Board	How to fix a loose turbo board on an AlphaEclipse 3500 Series A sign by replacing the board.
01-0005	Removing Coating on AlphaEclipse LED Board Connectors	How to remove excess conformal coating from the connectors on LED boards.
00-0005	Guidelines for Controlling Electrostatic Discharge Damage	How to prevent static electricity from damaging a sign

2.4 Controlling electrostatic discharge (ESD)



This equipment contains components that may be damaged by “static electricity”, or electrostatic discharge. To prevent this from happening, be sure to follow the guidelines in Adaptive Tech Memo 00-0005, “*Preventing Electrostatic Discharge (ESD) Damage*,” available on our Web site at <http://www.adaptivedisplays.com>.

2.5 Safety information

2.5.1 Equipment symbols




Chassis ground



Mains power (I = ON, O = OFF)




2.5.2 Warnings and cautions



2.5.3 Battery backup

In the event of a power loss, backup batteries in an AlphaEclipse sign provide short-term power in order to retain information such as messages and time settings.

Backup batteries are soldered to the controller board and should not be replaced by anyone other than a qualified Adaptive technician.



3.0 Equipment description

3.1 Overview

The AlphaEclipse 3500 series signs are one- to four-line outdoor LED signs that can be used to display text or graphic messages. These messages can be displayed on an AlphaEclipse sign using AlphaNET software and the following methods:

- From one AlphaEclipse sign to another
- From a computer connected to a wireless transmitter to a wireless receiver inside an AlphaEclipse sign
- From a computer connected to a transmitting modem to a receiving modem inside an AlphaEclipse sign
- From a computer connected directly to an AlphaEclipse sign




Figure 1: Anatomy of an AlphaEclipse 3500 sign

3.2 Technical specifications

3.2.1 Outside view

Table 4: Outside view of AlphaEclipse Series B sign

Shown below is a 2-line sign (64 x 16 LED matrix). Other sign sizes are similar.

Item	Name	Description
A	Power conduit	Access for electrical power. Must be sealed with weather-proof conduit during installation.
B	Signal and temperature probe conduit	Access for communication signals and temperature probe. Must be sealed with weather-proof conduit during installation.
C	Wireless transceiver antenna conduit	Access for antenna for optional wireless transceiver.
D	Lifting eyebolt	Used to lift the sign. Should <i>not</i> be used to mount the sign.
E	Fan covers	Weather-resistant louvers allow air movement through the sign.
F	Locking latch	Locks the sign closed. Requires key (included). Number of latches depends on the width of the sign.
G	Door	Opens for access to internal sign components. Gas cylinders hold the open door in place.
H	LED lens cover	Polycarbonate lens cover in the front access cover.
I	Photocell	Senses available light and dims the LEDs at sunset. The LEDs are dimmed by 50% (default setting).
J	Mounting brackets	American Standard 6061-T6 extruded aluminum: 0.25" x 1.5" x 2.0" (ASTM B 308).

3.2.2 Inside view

Table 5: Inside view of AlphaEclipse Series B sign




Table 5: Inside view of AlphaEclipse Series B sign

Four-Line Sign			
	Item	Name	Part #
A	Power supply fan, 120V		Circulates air in the sign.
	Power supply fan, 240V		
B	Heater	—	Not part of a Series B sign.
C	Power supply		Supplies power to fans, controller board, and LED board.

Table 5: Inside view of AlphaEclipse Series B sign






D	Exhaust fan, 120V		Dissipates heat from sign.
	Exhaust fan, 240V		
E	Controller board		Controls sign operation.
	Turbo Extender board		Plugs into the controller board and communicates with the sign's LED boards.
F	Modem kit, 120V		Allows sending messages to sign via a modem (optional).
	Modem kit, 240V		
	Transceiver kit, 120V		Allows sending messages to sign via wireless transmitter (optional).
	Transceiver kit, 240V		
G	Signal I/O terminal block		<p>Used for RS232 or RS485 communication with sign:</p> 
H	Wireless transceiver antenna conduit opening		Used to connect antenna to the optional wireless transceiver.
I	Signal wire conduit opening		Used to run an RS232 or RS485 signal wire to sign.
J	Photocell		Contains light-sensitive photocell used to dim the sign's LEDs
K	Power line conduit opening		Wires from power supply terminal block are run through this opening to a suitable power source.
L	Power supply terminal block		Used to connect the sign to an appropriate power supply.
M	Surge suppressor		<p>Protects the sign from electrical surges. Two suppressors (circled below) are used per sign.</p> 
N	Power switch		Used to disconnect sign from power source.
O	Line filter		Removes electrical noise (EMI) from power supply connection.
P	Heater thermostat		Not part of a Series B sign.
Q	Exhaust fan thermostat		Turns on exhaust fans when inside of unit gets too hot.
R	Overtemp thermostat		Not part of a Series B sign.

Table 5: Inside view of AlphaEclipse Series B sign

S	5V connection terminal		<p>Provides power to the LED boards.</p> 
T	120/240V connection terminal		<p>An all-plastic terminal strip that provides power to the power supplies and fans (6-terminal version shown below).</p> 
U	Shutdown thermostat		<p>Turns off the sign when it overheats (see “ In order to protect itself from damage, a sign will automatically turn on its exhaust fans, dim the LEDS, or turn itself off when the sign reaches a predetermined internal temperature.” on page 21).</p> 

3.2.3 Physical and electrical specifications

Table 6: Series B sign physical and electrical specifications

Lines	Rows (pixels)	Columns (pixels)	Dimensions (W x H x D ³ in inches)	Approximate weight (pounds)	Rated input current (amperes)		LED boards	Power supplies	Fans	
					@ 120 VAC ¹	@ 240 VAC			Exhaust (120 mm)	Internal ² (80 mm)
1	8	32	54.5 x 18.31 x 7.12	90	1.42	0.71	4	1	2	1
	8	64	97.8 x 18.31 x 7.12	140	2.33	1.17	8	2	2	2
	8	80	119.8 x 18.31 x 7.12	160	2.71	1.36	10	2	2	2
	8	96	141.8 x 18.31 x 7.12	190	3.10	1.55	12	2	2	2
	8	112	163.8 x 18.31 x 7.12	220	3.63	1.81	14	3	2	3
	8	128	185.8 x 18.31 x 7.12	240	4.01	2.00	16	3	2	3
	8	144	207.8 x 18.31 x 7.12	260	4.39	2.19	18	3	2	3
2	16	64	97.8 x 29.31 x 7.12	185	4.16	2.08	16	3	2	4
	16	80	119.8 x 29.31 x 7.12	220	5.22	2.61	20	4	4	4
	16	96	141.8 x 29.31 x 7.12	250	5.98	2.99	24	4	4	4
	16	112	163.8 x 29.31 x 7.12	285	7.04	3.52	28	5	4	6
	16	128	185.8 x 29.31 x 7.12	320	7.80	3.90	32	6	4	6
	16	144	207.8 x 29.31 x 7.12	355	8.57	4.28	36	6	4	6
3	24	64	97.8 x 40.0 x 7.12	440	6.28	3.14	24	4	4	6
	24	80	119.8 x 40.0 x 7.12	465	7.42	3.71	30	5	4	6
	24	96	141.8 x 40.0 x 7.12	485	8.57	4.28	36	6	4	6
	24	112	163.8 x 40.0 x 7.12	515	10.46 [*]	5.23	42	7	6	9
	24	128	185.8 x 40.0 x 7.12	535	11.60 [*]	5.80	48	8	6	9
	24	144	207.8 x 40.0 x 7.12	575	12.75 [*]	6.37	54	9	6	9
4	32	64	97.8 x 51.0 x 7.12	480	8.10	4.05	32	6	4	8
	32	80	119.8 x 51.0 x 7.12	505	9.93	4.96	40	7	6	8
	32	96	141.8 x 51.0 x 7.12	535	11.45 [*]	5.73	48	8	6	8
	32	112	163.8 x 51.0 x 7.12	560	13.88 [*]	6.94	56	10	8	12
	32	128	185.8 x 51.0 x 7.12	590	15.40 [*]	7.70	64	11	8	12
	32	144	207.8 x 51.0 x 7.12	635	16.92 [*]	8.46	72	12	8	12

NOTES:

¹ Signs are connected to a power source with either:

- 1 line of power or single ganged

- 2 lines of 120 VAC power or dual ganged, marked with asterisk (*) in above table. Each power line must be connected to an independent, 20A circuit.

² Signs equipped with heaters have an additional fan on the main panel.

³ Depth measurement ("D") includes the sign mounting bracket.

3.3 Equipment identification

Equipment labels are located:

- on the back of a sign.
- inside a sign.

Table 7: Series B sign equipment identification

Item	Name	Description
A	Model number	<p>3500 - 64x16 - A</p> <p>LED lamp color: A = Amber, R = Red</p> <p>Width (pixel columns) x Height (pixel rows)</p> <p>LED lamp viewing angle: 00 = 30°, 01 = 70°</p> <p>1.4" pitch, 4 led lamps per pixel</p>
B	Series letter	Indicates a basic design revision (only appears on the Series B label).
C	Electrical information	Input voltage, frequency, and amperage.
D	Date of manufacture	Month, day, and year the sign was made.
E	Serial number	Consecutive, unique identification number.

3.4 EMI compliance

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with installation guidelines, may cause harmful interference to radio

communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

3.5 Temperature protection

In order to protect itself from damage, a sign will automatically turn on its exhaust fans, dim the LEDs, or turn itself off when the sign reaches a predetermined internal temperature.

Table 8: Series B sign temperature protection

Internal sign temperature:	< 30°C (86°F)	30° - 49°C (86° - 120°F)	50° - 70°C (122° - 158°F)	71° - 81°C (160° - 178°F)	82°C or greater (180°F)
LEDs:	Normal brightness		Dim ¹	Off ²	Off ³
Controller board:	On				
Power supplies:	On				
Exhaust fans:⁴	Off	On			
<p>¹ Between 50° - 60°C (122° - 140°F), LED brightness can decrease between 62.5% - 100% of normal, depending on display load. Between 60° - 65°C (140° - 149°F), LED brightness can decrease between 50% - 87.5% of normal, depending on display load. Between 65° - 70°C (149° - 158°F), LED brightness can decrease between 37.5% - 75% of normal, depending on display load. (<i>Display load</i> means the number of LEDs that are on. For example, a graphic that lights up most of a sign's LEDs will have more of a display load than a simple text message that lights up only some LEDs.)</p> <p>² When the LEDs are turned off because the sign is too hot, two LEDs in the left-most corner will remain on to indicate a thermal shutdown.</p> <p>³ All LEDs will be off.</p> <p>⁴ At or above 30° C (86° F), the exhaust fans are switched on by the exhaust fan thermostat. If the temperature drops to 20° C (67° F), then the exhaust fans are turned off.</p>					

3.6 Optional equipment

3.6.1 Temperature probe option

See “4.1.4 Mounting a temperature probe” on page 29.

3.6.2 Modem option

This option allows messages to be sent from a computer that has a transmitting modem to a sign that has a receiving modem installed. Each modem must be attached to its own phone line.

NOTE: The modem option only includes the installation of a receiving modem in a sign. The purchase and installation of the transmitting modem is the responsibility of the sign buyer.

The US Robotics 56K modem is used as the receiving modem. This brand is also recommended as the transmitting modem which would be attached to the computer sending message to a sign.




3.6.2.1 Receiving modem

The receiving modem is installed inside a sign at the factory.

- Receiving modem DIP switch settings

The eight DIP switches on the US Robotics receiving modem are set as follows:

Table 9: US Robotics modem DIP switch settings




1	2	3	4	5	6	7	8
On	Off	On	On	Off	Off	Off	On
Modem ignores DTR	Verbal (word) result codes	Display result codes	Do not echo offline commands	Auto answer on	Carrier detect on	Load user-defined configuration from nonvolatile memory (NVRAM)	Smart mode (recognize AT command set)

- Receiving modem software configuration

The following AT command is sent to the modem with a program like HyperTerminal:

Table 10: US Robotics modem AT command setup string

 <p style="text-align: center;">AT&H0&R1&B1&N6&Y0&W0</p>					
Disables flow control	Modem ignores RTS	Fixed serial port rate	Connection speed = 9600 baud	Break handling: destructive, but does not send break.	Writes this current setup to Profile 0 in nonvolatile memory (NVRAM)

3.6.2.2 Transmitting modem

The US Robotics 56K modem is recommended for use as the transmitting modem. This modem is connected to the messaging computer and does not require any special setup for sending messages to a sign.

3.6.3 Wireless transceiver option

NOTE: The following information applies to Series B signs which are equipped with the Locus OS2400-232 transceiver (shown below).



For this option, one wireless transceiver (Master) is connected to the messaging computer and sends messages to another transceiver (Receive) inside a sign. Both transceivers require antennas and both are programmed at the factory.

3.6.3.1 Transceiver setup

NOTE: For more information about the Locus OS2400-232, see the product manual **OS2400 Radio Modem User's Manual** or visit the company's web site: <http://www.overairsolutions.com>.

Using the OverAir Solutions software from Locus, the following parameters were set for the master and the remote transceivers:

Table 11: Locus OS2400-232 transceiver setup


Parameter	Master transceiver (connected to messaging computer)	Receive transceiver (inside sign)
Network name:	Network 1	
Network type:	Point to point	
Network channel:	1	
Radio name:	Master	Receive
Baud rate:	9600	9600
Parity:	None	None
Data bits:	8	8
Stop bits:	1	1
Handshaking:	None	None
Transmit power:	Max	Max

3.6.3.2 Antenna installation

Follow these guidelines for mounting the remote transceiver antenna:

- Install the antenna and bracket on a support structure other than the sign or the sign's mounting brackets. Do NOT drill a hole in the sign enclosure.
- Install the antenna in a location that will allow optimum line-of-sight transmission and reception of signals between the sending transceiver and the antenna. Do not install the antenna so that the sign is between the sending transceiver and the receiving antenna.

- Install the antenna in an unobstructed area, keeping adequate clearance from any objects that could block the signal.
- Install the antenna in a more elevated location than the sign, and, if possible, keep it vertical.
- Mount the sign as shown:



3.6.4 Fiber optic modem option

3.6.4.1 Description

The fiber optic modem option allows messages to be sent from the messaging computer to a sign at distances up to 2 miles away. Fiber optic transmissions are not subject to electrical noise, ensure data security because eavesdropping is virtually impossible, and electrically isolate a computer from a sign so there is no spark hazard.

Two fiber optic mini modems are necessary:

- a mini modem inside the sign connected with the 1051-9019 adapter, and
- a mini modem connected to the computer which will be used to send messages to the sign. The 1051-9019 adapter is not used. However, a RS232 cable (DB25-to-DB9 or DB25-to-DB25) is needed to connect this mini modem to a computer COM (RS232) port.




Figure 2: Black Box ME605A async fiber optic mini modem (left) and 1051-9019 adapter (right)

3.6.4.2 Specifications

Table 12: Fiber optic mini modem specifications


Data rate:	Up to 19.2 Kbps
Pulse width distortion:	Less than 25%
Transmission line:	Duplex optical cable
Transmission mode:	Asynchronous, full- or half-duplex
Transmission controls:	Carrier constantly on or controlled by RTS
Optical output levels:	-28 dBm into 100/140 fiber -32 dBm into 62.5/125 fiber -36 dBm into 50/125 fiber
Receiver sensitivity:	-45 dBm
Operating wavelength:	850 nm
Operating range:	Maximum range is 2 miles (3 km) of continuous fiber with the following fibers: 100/140 fiber with attenuation of 4 dB/km 62.5/125 fiber with attenuation of 3.5 dB/km 50/125 fiber with attenuation of 3 dB/km
Indicators:	One power LED
Terminal interface:	One ITU V.24/EIA RS232C integral DB25 connector
Fiber optic interface:	Two ST connectors
Operating conditions:	Temperature — 32 to 122°F (0 to 50°C) Humidity — up to 90%, non condensing
Size:	0.7 x 2.1 x 3.1 in (1.8 x 5.3 x 7.8 cm)
Weight:	1.3 oz (36 g)

Table 13: Fiber optic modem setup switches

Switch	Function	Position	Factory setting																																																								
CARR	Selects carrier constantly on or controlled by RTS.	<ul style="list-style-type: none"> ON — carrier constantly on CL — carrier controlled by RTS 	ON																																																								
DLY	Selects RTS/CTS delay	<ul style="list-style-type: none"> 2 msec 15 msec 	2 msec																																																								
DCE/DTE	Selects DCE or DTE	<ul style="list-style-type: none"> DTE <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p style="text-align: center;">DTE position</p> <table style="width: 100%; border-collapse: collapse;"> <tr><td style="width: 20px;">TD</td><td style="width: 20px;">2</td><td style="width: 40px; border-bottom: 1px solid black;"></td><td style="width: 20px;">DI</td></tr> <tr><td>RD</td><td>3</td><td style="border-bottom: 1px solid black; text-align: center;">→</td><td>DO</td></tr> <tr><td>RTS</td><td>4</td><td style="border-bottom: 1px solid black;"></td><td>CD</td></tr> <tr><td>CTS</td><td>5</td><td style="border-bottom: 1px solid black;"></td><td>N.C.</td></tr> <tr><td>DSR</td><td>6</td><td style="border-bottom: 1px solid black;"></td><td>N.C.</td></tr> <tr><td>DCD</td><td>8</td><td style="border-bottom: 1px solid black;"></td><td>N.C.</td></tr> <tr><td>DTR</td><td>20</td><td style="border-bottom: 1px solid black; text-align: center;">← 300 ohm</td><td>+V</td></tr> </table> </div> DCE <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> <p style="text-align: center;">DCE position</p> <table style="width: 100%; border-collapse: collapse;"> <tr><td style="width: 20px;">TD</td><td style="width: 20px;">2</td><td style="width: 40px; border-bottom: 1px solid black; text-align: center;">→</td><td style="width: 20px;">DI</td></tr> <tr><td>RD</td><td>3</td><td style="border-bottom: 1px solid black; text-align: center;">←</td><td>DO</td></tr> <tr><td>RTS</td><td>4</td><td style="border-bottom: 1px solid black; text-align: center;">→</td><td>RTS</td></tr> <tr><td>CTS</td><td>5</td><td style="border-bottom: 1px solid black; text-align: center;">←</td><td style="border: 1px solid black; text-align: center;">D</td></tr> <tr><td>DSR</td><td>6</td><td style="border-bottom: 1px solid black; text-align: center;">← 300 ohm</td><td>+V</td></tr> <tr><td>DCD</td><td>8</td><td style="border-bottom: 1px solid black;"></td><td>CD</td></tr> <tr><td>DTR</td><td>20</td><td style="border-bottom: 1px solid black;"></td><td>N.C.</td></tr> </table> </div> 	TD	2		DI	RD	3	→	DO	RTS	4		CD	CTS	5		N.C.	DSR	6		N.C.	DCD	8		N.C.	DTR	20	← 300 ohm	+V	TD	2	→	DI	RD	3	←	DO	RTS	4	→	RTS	CTS	5	←	D	DSR	6	← 300 ohm	+V	DCD	8		CD	DTR	20		N.C.	DCE
TD	2		DI																																																								
RD	3	→	DO																																																								
RTS	4		CD																																																								
CTS	5		N.C.																																																								
DSR	6		N.C.																																																								
DCD	8		N.C.																																																								
DTR	20	← 300 ohm	+V																																																								
TD	2	→	DI																																																								
RD	3	←	DO																																																								
RTS	4	→	RTS																																																								
CTS	5	←	D																																																								
DSR	6	← 300 ohm	+V																																																								
DCD	8		CD																																																								
DTR	20		N.C.																																																								

4.0 Installation

4.1 Mechanical installation



4.1.1 Designing the support structure

Support structure design depends on the mounting methods, sign size, sign weight, and wind loading.

Support structure design should only be done by a qualified individual. It is the customer's responsibility to ensure that the support structure and mounting hardware are adequate.

It is the installer's responsibility to ensure that the support structure and hardware are capable of supporting the sign and in compliance with all applicable building codes.

Adaptive is not responsible for installations or the structural integrity of support structures done by others.

4.1.2 Lifting the sign

Use the two eyebolts on the sign to lift the display.

NOTE: The 3/8-inch eyebolts on the sign are designed to be used with a lifting bar (shown below).





Figure 3: Lifting an AlphaEclipse 3500 sign

4.1.3 Mounting the sign

Because every installation site is unique, there is no single Adaptive-approved procedure for mounting AlphaEclipse signs.

However, follow these guideline when installing a sign:

- Consult with a professional sign installer to determine the proper mounting system and to comply with all applicable building codes.
- Only use the sign's mounting support bars to mount the sign. *Mounting to any other parts of the sign will void the warranty.*
- Both mounting support bars should be used to mount the sign.
- Drill holes as needed in the sign's mounting support bars for fasteners. *Drilling holes in any other place on the sign will void the warranty.* Follow these guidelines when drilling holes in the mounting support bars:
 - ❑ Drill the minimum number of holes necessary.
 - ❑ The distance from the center line of a mounting bolt to the outside edge of a mounting support bar should NOT be less than two times the diameter of the fasteners.
 - ❑ To prevent bi-metal corrosion, dissimilar material should be isolated when mounting the sign.
- Allow fan clearance as shown below:



For monument-type installations where the sign is enclosed, the fan covers should be ducted so that the exhaust air is *not* recirculated into the sign. *If this is not done, the sign could overheat and shut down.*

Adaptive recommends isolating the fresh air intake fan covers from the exhaust fan covers.


Figure 4: Mounting an AlphaEclipse sign

4.1.4 Mounting a temperature probe



NOTE: The temperature probe used on a Series A sign cannot be used on a Series B sign. Also, a Series B temperature probe cannot be used on a Series A sign.

- 1 Mount the temperature probe vertically using the mounting plate on each side of the probe. The temperature probe can be mounted on either a flat or a curved surface.**
- A good place to locate the temperature probe is underneath the eaves of a protected overhang. Choose a location where air movement is not restricted by nearby walls or other obstructions. Mount the temperature probe housing so that convection currents, or rising hot air flows, are not blocked by the mounting plates.
 - A location on the north side of a building, at least 6 feet off the ground, or other large structure will afford protection from the afternoon sun. Shield the probe from the effect of the direct sun, reflected heat, or any nearby sources of heat, such as chimneys, vents, or HVAC ducts.
 - A light-colored background is preferable to a dark-colored mounting background. A location above vegetation is preferable to a location above asphalt or blacktop.

2 Connect the temperature probe to the controller board.



4.2 Electrical installation



4.2.1 Guidelines for electrical installation


- Electrical installation should only be attempted by a qualified electrician.
- Electrical connection must comply with all applicable national and local codes. In the United States, refer especially to Articles 250 (grounding) and 600 (electric signs) of the National Electrical Code.
- Inspect all internal sign cabling for proper connection and seating.
- All power wiring must be from a switched, fused power source.
- A two-pole disconnect device must be installed in the building wiring for each branch circuit supplying the sign.
- The sign must be properly earth grounded. The sign's support structure should *not* be used as ground.
- Run separate conduits for signal wires (for example, RS232, RS485) and for power wires.
- All electrical connections must be watertight.
- Use minimum 80° C copper wire only. Torque terminals to 7-10 inch/pounds. Utiliser uniquement un fil en cuivre pouvant supporter 80° C minimum. Serrer les bornes à 0,79 N/m – 1,13 N/m.

4.2.2 Opening the sign

NOTE: Do NOT attempt this procedure if there are strong winds or if it is raining or snowing.


1

Remove power from the sign.



⚠ WARNING

Hazardous voltage.
Contact with high voltage may cause death or serious injury.
Always disconnect power to unit prior to servicing. SM1000A




⚠ WARNING


Hazardous voltage.
After removing power, wait **AT LEAST ONE MINUTE** before continuing this procedure. Otherwise, serious injury or death may occur. SM1012




2

Unlock the sign door with a latch key.



Locking latch
Locking latch
Locking latch



Latch key


3

Lift the door up.

NOTE: Signs equipped with gas shock absorbers can open quickly.

NOTE: Long signs may require a person at each end to help open the sign.

⚠ WARNING




Possible fall hazard.
Remain clear of door when opening.
Install prop bar when door is open.

SM1005B


Installation — Electrical installation

31

4 Fasten a safety bar on each side of the sign.




5 Remove the screw from each vertical rail.



Lift up the LED boards.

7 Lower and fasten the prop rod(s).


Prop bar



8 Put the internal power switch in the OFF (0) position.



Internal power switch





4.2.3 Installing signal wiring

- 1** **Connect the sign to the messaging computer.**
 - ❑ See “5.2 Computer-to-sign connection methods” on page 38.
- 2** **Connect the signs together (for multiple signs only).**
 - ❑ See “5.3 Sign-to-sign connection methods” on page 46.

4.2.4 Connecting power to the sign

NOTE: Electrical installation should only be attempted by a qualified electrician. Electrical connection must comply with all applicable national and local codes.



- 1** **Connect the sign to an appropriate power source.**

AlphaEclipse™ sign
(inside view, right side)

Terminal block	120V	240V
1	LINE	LINE 1
2	NEUTRAL	LINE 2
3	GROUND	GROUND

Power line conduit opening. Connect power lines to a **20-amp dedicated service breaker.**

Signal wire conduit opening
- 2** **Ground the sign according to the applicable electrical codes.**

NOTE: The sign's support structure should *not* be used as ground.

4.2.5 Closing the sign

1	Put the internal power switch in the ON (I) position.
2	Place each prop rod in the up position
3	Lower the LED boards.
4	Attach a screw to each vertical rail.
5	Place each safety bar in the up position.
6	Push down the sign door until it latches.

4.3 Installation checkout test

1 Apply power to the sign.

2 Observe the sign's powerup messages.

Sequence	Example message	Description
1	DIP DISABLED	Will only appear if the sign's DIP switches are under software control (AlphaNET Diagnostics software).
2	11705001D ECLIPSE	Main FLASH firmware part number ("11705001") and revision ("D").
3	ECLIPSE M-096x016	Sign model, Master/Slave mode, and sign size (in this case, the "ECLIPSE" means that this is an AlphaEclipse sign, "M" indicates that the sign is a "Master", and an "096x016" means that the sign is 96 columns long by 16 rows high).
4	CLEAR MEMORY	Will only appear if DIP switch #10 in Bank 1 is set to ON. This message indicates that the sign's memory will be erased each time the sign is turned on. This means that all messages will be erased each time.
5	SER ADDR 0C HEX	Serial address of sign in hexadecimal (in this case, the hexadecimal address is "0C" which is 12 in decimal).
6	SER.. DATA 9600, 8n1	Baud rate, number of data bits, parity, number of stop bits (in this case, 9600 baud, 8 data bits, no parity, and 1 stop bit).
7	PERF REV 11704001A0200	Part number and revision of the peripheral FLASH firmware (in this case, the part number is "11704001D" and the revision number is 2.0 ["0200"]).
8	FPGA REV 26111701 1.1	Part number and revision of the sign's programmable logic chip (in this case, the part number is "26111601" and the revision number is "1.1").
9	RAM 1 RAM 128K	RAM location ("1", "2", and so on) and RAM size ("128K").
10	1:22 AM MON. 6/12/03	Time, day of week, and date set in the sign.
11	CHK FLASH FLASH OK	Main FLASH memory status.
12	LO = 5DF7 HI = 2281	Low and high checksums for Main FLASH memory

3 Check if the messaging computer can communicate with the sign(s).

- Follow the "8.2.1 PC-TO-SIGN CHECK procedure" on page 79.
- If the PC-TO-SIGN CHECK procedure fails, see "8.1 Common sign problems" on page 61.

5.0 Networking signs

In order to display messages on an AlphaEclipse sign, a sign must be connected to the messaging computer which has AlphaNET software installed.

5.1 Series A and B sign networking comparison

Table 14: Series A and B sign networking comparison

	Computer-to-sign connection							Sign-to-sign connection	
	¹ External connection box (RS232)	² External connection box (RS485)	Converter Box III (RS485)	Fiber optic ³	Ethernet ⁴	Modem	Wireless	Master/Master ⁵	Master/Slave ⁶
Series A sign:	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
Series B sign:	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

NOTES:

¹ Used to connect a computer to a sign using a short (< 50 foot) RS232 cable.

² Used to connect an IR Message Loader to a sign in order to download messages from the loader to the sign.

³ A fiber optic computer-to-sign connection is just a RS232 connection because the two fiber optic modems use RS232.

⁴ Neither a Series A or B sign can be connected directly to an Ethernet LAN. However, it is possible to use a serial interface (like the Lantronix MSS485) to connect a Series A or B sign to a 10BASE-T Ethernet LAN.

⁵ Master/Master = All signs are wired to each other using a RS485 network. Messages come into the first Master sign via an RS232 connection to a modem, wireless transceiver, or a computer. Each sign can display its own, unique message. It is possible to connect Series A and Series B signs together into a Master/Master network.

⁶ Master/Slave = All signs are wired together using either a “turbo” network (Series A) or a special RS485 network (Series B). Messages come into the first Master sign via a RS232 connection to a modem, wireless transceiver, or a computer. All signs will display the *same* message at the *same* time. **It is NOT possible to connect Series A and Series B signs together into a Master/Slave network.**

5.2 Computer-to-sign connection methods

There are a number of ways to connect an AlphaEclipse Series B signs *to a computer*:

- External connection box (RS232)
- External connection box (RS485) — for IR Message Loader
- Converter Box III (RS485)
- Fiber optic
- Ethernet
- Modem
- Wireless

Table 15: Computer-to-sign connection methods

Distance from computer to sign (feet)	External connection box (RS232)	External connection box (RS485)	Converter Box III (RS485)	Fiber optic ²	Ethernet ³	Modem ¹	Wireless ^{1,4}
up to 50	Yes	Yes	Yes	Yes	Yes	Yes	Yes
50 to 1000	No	Yes	Yes	Yes	Yes	Yes	Yes
1000 - 4000	No	Yes	Yes	Yes	Yes	Yes	Yes
4000+	No	No	No	Yes	Yes	Yes	No

NOTES:

¹ Installed and configured at the factory.

² For a fiber optic data connection, the maximum distance between the sign and computer is 2 miles (~10,000 feet).


³ A sign cannot be connected directly to the Ethernet. A Lantronics MSS485-T Serial Server must be used as an interface.

⁴ Maximum *indoor* range of a Locus OS2400-232 or a Zeus ZLRT2100 wireless transceiver is about 1500 feet. Actual operating range depends on local environment, including obstructions and electrical interference. The maximum *outdoor* range of a Locus OS2400-232 or a Zeus ZLRT2100 wireless transceiver is about 10,000 feet (about 2 miles). Actual operating range depends on local environment, including obstructions and electrical interference.

5.2.1 External connection box (RS232) computer-to-sign connection


External connection box (RS232)

Series B — AlphaEclipse™ 3500




In order to display messages on a sign, the messaging computer must be connected to the sign, such as with an External connection box. The connection box is typically attached near the base of the sign's mounting pole. The box will have either a RS232 or a RS485 connection for a computer or an IR Message Loader. An RS232 External connection box can be up to 50 feet from a sign.


METHOD 1 — SERIAL I/O terminal block connection:




METHOD 2 — SERIAL PORT connection:



There are two methods of wiring an External connection box to a sign:
METHOD 1: If a sign has a SERIAL I/O terminal block, then wire the box to this block (above).
METHOD 2: Otherwise, wire the box directly to the SERIAL PORT on the sign's Controller board (right).



Controller board DIP switches:



Use the DIP switch settings shown on the left when connecting a single sign to an External connection box.

If more than one sign is connected to a connection box, then the DIP switch settings will be different. For example, only the first and the last signs in the network need to be terminated. All other signs should have their two, RS485 termination DIP switches set to OFF.

Also, each sign should have its own, unique sign address: the first sign should be set to sign address 01 (as shown), the second sign should be set to sign address 02, and so on.

5.2.2 External connection box (RS485) computer-to-sign connection

External connection box (RS485) — for IR Message Loader Series B — AlphaEclipse™ 3500

Overview

In order to display messages on a sign, the messaging computer must be connected to the sign, such as with an External connection box.

The connection box is typically attached near the base of the sign's mounting pole.

The box will have either a RS232 or a RS485 connection for a computer or an IR Message Loader.

An RS485 External connection box allows an IR Message Loader to download messages to a sign.

Wiring

METHOD 1 — SERIAL I/O terminal block connection:

External connection box (gray area)

To IR Message Loader

Pinout for 4-position Modular Network Adapter (pn 4331-0602) Female

There are two methods of wiring an External connection box to a sign:

METHOD 1: If a sign has a SERIAL I/O terminal block, then wire the box to this block (above).

METHOD 2: Otherwise, wire the box directly to the SERIAL PORT on the sign's Controller board (right).

METHOD 2 — SERIAL PORT connection:

From External connection box

DIP switches

Controller board DIP switches:

Use the DIP switch settings shown on the left when connecting a single sign to an External connection box.

If more than one sign is connected to a connection box, then the DIP switch settings will be different. For example, only the first and the last signs in the network need to be terminated. All other signs should have their two, RS485 termination DIP switches set to OFF.

Also, each sign should have its own, unique sign address: the first sign should be set to sign address 01 (as shown), the second sign should be set to sign address 02, and so on.

Sign address = 01 (switch #1 ON)
 RS485 termination = ON (switches #1 and #2 both ON)


DRAWING REVISION 2

5.2.3 Converter Box III (RS485) computer-to-sign connection


Series B — AlphaEclipse™ 3500

Converter Box III (RS485)


Overview



Wiring




DIP switches



DRAWING REVISION 2

5.2.4 Fiber optic computer-to-sign connection






DRAWING REVISION 4

5.2.5 Ethernet computer-to-sign connection

Series B — AlphaEclipse™ 3500


Ethernet connection



5.2.6 Modem computer-to-sign connection


Series B — AlphaEclipse™ 3500

Modem connection




Overview

In order to display messages on a sign, the messaging computer must be connected to the sign, such as with a pair of telephone modems (a Transmitting modem attached to the messaging computer and a Receiving modem attached to a sign).
Modems can connect to a sign that is almost anywhere. However, a sign must have its own phone line.



Wiring




DIP switches


5.2.7 Wireless computer-to-sign connection

Wireless connection (Locus transeiver)


Series B — AlphaEclipse™ 3500




METHOD 1 — SERIAL I/O terminal block connection:



METHOD 2 — SERIAL PORT connection:



Controller board DIP switches:



Use the DIP switch settings shown on the left when connecting a single sign to a wireless transceiver.



If more than one sign is connected to a transceiver, then the DIP switch settings will be different. For example, only the first and the last signs in the network need to be terminated. All other signs should have their two, RS485 termination DIP switches set to OFF. Also, each sign should have its own, unique sign address: the first sign should be set to sign address 01 (as shown), the second sign should be set to sign address 02, and so on.

5.3 Sign-to-sign connection methods

There are two ways to *interconnect* two or more AlphaEclipse signs:

- Master/Master
- Master/Slave

Table 16: Sign-to-sign connection methods

	Description
<p>Master/Master:</p>	<p>Signs connected this way can each display a unique message. Messages come into the first Master sign via an RS232 connection to a modem, wireless transceiver, or a computer.</p>  <p style="text-align: center;">Figure 5: Master/Master sign-to-sign connection</p> <p>NOTES:</p> <ul style="list-style-type: none"> • Messaging — a message can be displayed on all the signs in a Master/Master network by sending the message to sign address “00”. Also, if each sign in a Master/Master network has a unique serial address (for example, “01”, “02”, and so on), then a different message can be sent to and displayed on each sign. • Temperature — to display the temperature on the signs in a Master/Master network, a temperature probe must be connected to <i>each</i> sign. If a sign attempts to display the temperature and does not have a temperature probe attached, the sign will display “ERR” in place of the temperature. • Time — in Master/Master mode, the time is synchronized whenever a message is sent using the AlphaNET software.
<p>Master/Slave:</p>	<p>Signs connected this way always display the <i>same</i> message at the <i>same</i> time. This is called <i>simultaneous messaging</i> and is often used when signs are mounted back-to-back. Messages come into the Master sign via an RS232 connection to a modem, wireless transceiver, or a computer.</p>  <p style="text-align: center;">Figure 6: Master/Slave sign-to-sign connection</p> <p>NOTES:</p> <ul style="list-style-type: none"> • Messaging — a message will be displayed <i>simultaneously</i> on all the signs in a Master/Slave network by sending the message to sign address “00” or to <i>all</i> the sign addresses (“01”, “02”, and so on). • Temperature — to display the temperature on the signs in a Master/Slave network, a temperature probe must be connected to the Master sign. • Time — in Master/Slave mode, the time is synchronized at the top of every hour and also whenever a message is sent using the AlphaNET software.

NOTE: An AlphaEclipse sign’s connection to a computer or to other signs must be properly “terminated” in order for the sign to operate. (See “5.4 Termination” on page 49.)

5.3.1 Master/Master sign-to-sign connection


Series B — AlphaEclipse™ 3500

Master / Master sign connection


Overview

Two Series B signs connected as a Master/Master pair can each display a unique message — unlike a Master/Slave pair which always displays the same message at the same time. In a Master/Master sign pair, a message can be displayed on Master sign #1 by sending the message to sign address "01" or displayed on Master sign #2 by sending the message to sign address "02". Also, a message can be displayed on both Master signs by broadcasting the message to sign address "00".

Wiring



DIP switches



DRAWING REVISION 2

5.3.2 Master/Slave sign-to-sign connection


Series B — AlphaEclipse™ 3500

Master / Slave sign connection


Overview

Two Series B signs connected as a Master/Slave pair will both display the same message at the same time. Messages should be sent to both the Master and Slave signs. To do this, send all messages to sign address '00' or to all the sign addresses ('01', '02', and so on).

Wiring



DIP switches




DRAWING REVISION 2

5.4 Termination

When signs are networked together using RS485 connections, EOL (End-Of-Line) termination must be taken into account so that the signs will function properly.

Improperly terminated signs may be unable to display messages.


5.4.1 Termination DIP switches



5.4.2 Termination examples


- One-sign network using a Converter Box III:

Table 17: Termination on a one-sign network using a Converter Box III (Series B sign)




- One-sign network using a sign with an internal modem or wireless transceiver:

Table 18: Termination on a one-sign network using a sign with an internal modem or transceiver (Series B sign)



- Termination on multiple signs using RS485 networking:

Table 19: Termination on multiple signs using RS485 networking (Series B sign)



6.0 Basic operating instructions

The purpose of this section is to show how to set up AlphaNET messaging software in order to send messages to a sign. For more information, see the AlphaNET user manual (see “2.3 Related documentation” on page 9).

NOTE: Examples from AlphaNET version 3 software are shown below.

6.1 Basic setup for AlphaNET software

To send messages from a computer to a sign using AlphaNET software, this software must be set up based on how your computer is connected to the sign. To set up the software, you need to:

- Create a device
- Create a site
- Create and send messages

6.1.1 Create a device

Use the *Site Manager* in the AlphaNET software to create a device based on how your computer is connected to the sign:


- Wired (RS232 or RS485) — see “6.1.1.1 Device setup for a wired, wireless, or fiber optic connection” on page 52.
- Fiber optic — see “6.1.1.1 Device setup for a wired, wireless, or fiber optic connection” on page 52.
- Modem — see “6.1.1.2 Device setup for a Modem connection” on page 53.
- Wireless — see “6.1.1.1 Device setup for a wired, wireless, or fiber optic connection” on page 52.

6.1.1.1 Device setup for a wired, wireless, or fiber optic connection

1


In the AlphaNET software, open Site Manager. Then click *Edit > Connection Device > Add*. Select a *Local Wired* device for the messaging computer COM port you will be using. Then click *OK*.

Select one of these based on which COM port is wired to the sign.




2

Click the *Local Wired* device you just added and click *Edit*. Then click *OK* and go to “6.1.2.1 Site setup for a wired, wireless, or fiber optic connection” on page 54.




Data Format must be *8N1* for an AlphaEclipse 3500 sign.




6.1.1.2 Device setup for a Modem connection

1 In the AlphaNET software, open Site Manager. Then click *Edit > Connection Device > Add*. Select a *Modem* device for the messaging computer COM port you will be using. Then click *OK*.



Select one of these based on which COM port is wired to the sign.

2 Click the *Modem* device you just added and click *Edit*. Then click *OK* and go to “6.1.2.2 Site setup for a Modem connection” on page 55.



Use these settings.

Leave these blank.

6.1.2 Create a site

In AlphaNET software, a site must be created in order to send messages to a sign.

6.1.2.1 Site setup for a wired, wireless, or fiber optic connection

1

In Site Manager, click *File > New Site*. In the *Sign Info* tab, fill in the information for a new site.

Select *Alpha 2.0* for AlphaEclipse signs.

Select a wired *Connect Device*.

The screenshot shows the 'Site Editor' dialog box with the 'Sign Info' tab selected. The 'Site Description' section contains a text field for 'Site Name' with the value 'AlphaEclipse Wired Site'. Below it, the 'Compatibility' dropdown is set to 'Alpha 2.0'. To the right of the compatibility dropdown are two checkboxes: 'Full Color (RGB) Capable' (unchecked) and 'Use as an Editor transmit site' (checked). The 'Network Configuration' section has a 'Connection Device' dropdown set to 'Local Wired Com 1'. Below this are fields for 'Phone Number' and 'Cap Code', both currently empty. At the bottom left of this section is an unchecked checkbox labeled 'Enable error checking'. The dialog has 'OK', 'Cancel', 'Apply', and 'Help' buttons at the bottom.

When this is checked, messages sent from the *Message Editor* will be sent to the signs on this site.

2

Click the *Sign Info* tab. Make sure the sign address is set. Then click *OK*,

Type the sign address.

The screenshot shows the 'Site Editor' dialog box with the 'Sign Info' tab selected. The 'Sign Addresses' section has an 'Address List' text field containing '01'. Below this are three sections: 'Counters' with a 'Counter File...' button and a text field containing 'None'; 'Automode Table' with an 'Automode File...' button and a text field containing 'None'; and 'Tune File' with a 'Tune File...' button and a text field containing 'None'. To the right of these sections is the 'Tone on Receipt' section with radio buttons for 'None' (selected), 'Single Beep', 'Three Beeps', 'Tune File', and 'Custom Tone'. Below the radio buttons are 'Duration' and 'Repeat' spinners, both set to 2 and 0 respectively. At the bottom right is a 'Memory' section with a checked checkbox for 'Extended Memory'. The dialog has 'OK', 'Cancel', 'Apply', and 'Help' buttons at the bottom.


6.1.2.2 Site setup for a Modem connection

1 In Site Manager, click *File > New Site*. In the *Sign Info* tab, fill in the information for a new site.

Select *Alpha 2.0* for AlphaEclipse signs.

Select a modem *Connect Device*.


Telephone number of the modem inside the sign.



When this is checked, messages sent from the *Message Editor* will be sent to the signs on this site.


2 Click the *Sign Info* tab. Make sure the sign address is set. Then click *OK*,

Type the sign address.



6.1.3 Create and send a message


1 Open the Message Editor. Type a short test message.



2 Send this message to the sign by clicking *File > Transmit*.

Select *To Selected Signs*.

However, if the test message does not appear, transmit again, but this time select *To All Signs*.



6.2 Setting the time and date on a sign

Whenever a message is sent to a sign, the sign's clock is automatically updated to the time on the computer that send the message.

If your computer is on a different time zone than your sign, the time zone can be adjusted in the *Site Editor* by selecting the *Advanced* tab.

6.3 Setting the dimming time for a sign

1 Open the Site Manager. Double click the name of the site for the sign you want to dim.

Double click the site name.

2 Click the *Advanced* tab. Set the *Dimming Options*.

Used to adjust your computer's time zone to the sign's zone.

Dim On Time = when sign will dim to the *Brightness %*.

Dim Off Time = when sign will return to full brightness

7.0 Maintenance

Whenever a unit is opened, examine the inside thoroughly as itemized in the following table:

Table 20: Recommended general maintenance

<ul style="list-style-type: none">• Test exhaust fans to make sure they are operational.
<ul style="list-style-type: none">• Make sure power supply fans are running.
<ul style="list-style-type: none">• Make sure the bottom air intake vents are not clogged with debris.
<ul style="list-style-type: none">• Unclog water drain holes in the bottom of the unit.
<ul style="list-style-type: none">• Verify door seals are in place.
<ul style="list-style-type: none">• Verify sign mounting structure is secure.
<ul style="list-style-type: none">• Clean front window as required.
<ul style="list-style-type: none">• Clean inside of unit of any foreign material.
<ul style="list-style-type: none">• Check for signs of water leakage. Small leaks can be sealed with 3M Scotch-Seal Polyurethane adhesive Sealant 540 black.

8.0 Troubleshooting

The purpose of this section is to help a user fix a sign as quickly as possible using three types of troubleshooting procedures (see “8.2 Troubleshooting procedures” on page 78) that start relatively easy with testing that can be done on a computer but that get progressively more difficult:






Figure 7: Three-part troubleshooting process



8.1 Common sign problems

Problem type	Problem	Recommended solution
General	All LEDs are on.	page 67
	No LEDs are on.	page 68
	Letter “B”s fill the sign.	page 63
	Pattern of blocks and diagonal bars keep repeating.	page 62
Text and graphics	Startup message (“Impact . . . AlphaEclipse . . .”) keeps reappearing.	page 69
	Text and graphics appear dim.	page 70
	Text appears scrambled.	page 72
	Messages sent from AlphaNET software do not appear.	page 73
	Graphics sent from AlphaNET software do not appear.	page 74
Temperature	Temperature or “ERR” appears in upper right.	page 64
	Temperature is inaccurate.	page 65
	Temperature displayed on two signs is different.	page 66
LED boards	All LEDs are on.	page 67
	No LEDs are on.	page 68
	Only two LEDs in the upper left are on.	page 71
	One or more LED boards are off.	page 75
	Entire row of LED boards is off.	page 76
	Entire section of sign is off.	page 77



8.1.1 Problem: Pattern of blocks and diagonal bars keep repeating

<p>SIGN APPEARANCE:</p>	 <p>The top diagram shows a repeating pattern of blocks and diagonal bars. The bottom diagram shows a similar pattern with a different arrangement of blocks and diagonal bars.</p>
<p>POSSIBLE CAUSE:</p>	<p>• Sign is set in Test Pattern Mode (see Table 21, “Test Mode information,” on page 97).</p>
<p>SUGGESTED SOLUTION:</p>	<p>Follow the procedure listed below:</p>  <p>The flowchart consists of three chevron-shaped boxes pointing to the right: "Messaging Computer Procedures", "Cables and Interfaces Procedures", and "Sign Procedures". A red arrow points down from the "Messaging Computer Procedures" box to the text "TEST MODES (page 97)".</p> <p>• TEST MODES (page 97)</p>


8.1.2 Problem: Letter “B”’s fill the sign

<p>SIGN APPEARANCE:</p>	 <p>FOLLOWED BY</p> <p>Various numbers and letters will appear in this area.</p>
<p>POSSIBLE CAUSE:</p>	<ul style="list-style-type: none"> • Sign is set in Production Test Mode (see Table 21, “Test Mode information,” on page 97).
<p>SUGGESTED SOLUTION:</p>	<p>Follow the procedure listed below:</p>  <ul style="list-style-type: none"> • TEST MODES (page 97)


8.1.3 Problem: Temperature or “ERR” appears in upper right

<p>SIGN APPEARANCE:</p>	 <p style="text-align: center;">OR</p>
<p>POSSIBLE CAUSE:</p>	<ul style="list-style-type: none"> • Sign is set in Temperature Test Mode (see Table 21, “Test Mode information,” on page 97).
<p>SUGGESTED SOLUTION:</p>	<p>Follow the procedure listed below:</p> <div style="text-align: center;">  </div> <ul style="list-style-type: none"> • TEST MODES (page 97)



8.1.4 Problem: Temperature is inaccurate

SIGN APPEARANCE:	Temperature displayed on sign does not match the actual temperature.
POSSIBLE CAUSE:	<ul style="list-style-type: none"> • Temperature probe is not calibrated correctly.
SUGGESTED SOLUTION:	<p>Follow the procedure listed below:</p>  <pre> graph LR A[Messaging Computer Procedures] --> B[Cables and Interfaces Procedures] B --> C[Sign Procedures] </pre> <ul style="list-style-type: none"> • TEMP PROBE CHECK (page 114)



8.1.5 Problem: Temperature displayed on two signs is inaccurate

SIGN APPEARANCE:	Temperature shown on two or more signs is not the same.
POSSIBLE CAUSE:	<ul style="list-style-type: none"> • Signs are not connected as a Master/Slave network. • Faulty temperature probe.
SUGGESTED SOLUTION:	<p>Follow the procedure listed below:</p> <div style="text-align: center;">  <pre> graph LR A[Messaging Computer Procedures] --> B[Cables and Interfaces Procedures] B --> C[Sign Procedures] C --> D[• TEMP PROBE FIX (page 115)] </pre> </div> <ul style="list-style-type: none"> • TEMP PROBE FIX (page 115)



8.1.6 Problem: All LEDs are on

<p>SIGN APPEARANCE:</p>	
<p>POSSIBLE CAUSE:</p>	<ul style="list-style-type: none"> • Sign is set in Test Match Mode (see Table 21, "Test Mode information," on page 97).
<p>SUGGESTED SOLUTION:</p>	<p>Follow the procedure listed below:</p> <div style="text-align: center;">  </div> <ul style="list-style-type: none"> • TEST MODES (page 97)



8.1.7 Problem: No LEDs are on

<p>SIGN APPEARANCE:</p>	
<p>POSSIBLE CAUSES:</p>	<ul style="list-style-type: none"> • User error with AlphaNET software. • Messaging computer not set up properly. • AlphaNET software problem. • External power switch off. • Internal power switch off. • Cable and/or interface problem. • Sign malfunction (DIP switches misconfigured, sign overheating, sign damage, and so on)
<p>SUGGESTED SOLUTIONS:</p>	<p>Follow the procedures listed below. Start on the left with “Messaging Computer Procedures” and work your way right to “Sign Procedures”:</p> <div style="text-align: center;">  </div> <ul style="list-style-type: none"> • PC-TO-SIGN check (page 79) • ALPHANETMESSAGE (page 82) • PC CHECK (page 84) • OUTSIDE INSPECTION (page 112) • SIGN RESTART (page 96) • INSIDE INSPECTION (page 113) • SIGN POWER (page 101) • SIGN FEEDBACK (page 99) • SIGN CHECK (page 104)



8.1.8 Problem: Startup message keeps reappearing

<p>SIGN APPEARANCE:</p>	<p>“Impact . . . AlphaEclipse . . . Series . . . Features . . . and . . . Functions . . .”</p> 
<p>POSSIBLE CAUSES:</p>	<p>Each of the following erases all messages from the sign and causes the demo message to appear:</p> <ul style="list-style-type: none"> • Bank 1 DIP switch #10 is set to on. • AlphaNET Diagnostics software <i>Actions > Clear Memory</i> used. • AlphaNET Diagnostics software <i>Actions > Configure Sign (Advanced) > Set Other Options > Demo Message</i> set to on.
<p>SUGGESTED SOLUTIONS:</p>	<p>Follow the procedures listed below. Start on the left with “Messaging Computer Procedures” and work your way right to “Sign Procedures”:</p>  <ul style="list-style-type: none"> • PC DIP SWITCH (page 116) • SIGN DIP SWITCH (page 117)








8.1.9 Problem: Text and graphics appear dim

<p>SIGN APPEARANCE:</p>	
<p>POSSIBLE CAUSES:</p>	<ul style="list-style-type: none"> • AlphaNET Diagnostics software <i>Actions > Configure Sign > Set Dim Times</i> and <i>Set Dimming Level</i> are causing the sign's loss of brightness. • The sign has automatically reduced brightness to protect itself from overheating (see "3.5 Temperature protection" on page 21).
<p>SUGGESTED SOLUTIONS:</p>	<p>Follow the procedures listed below. Start on the left with "Messaging Computer Procedures" and work your way right to "Sign Procedures":</p> <div style="text-align: center;">  </div> <div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <ul style="list-style-type: none"> • PC DIP SWITCH (page 116) • OVERHEAT CHECK (page 118) </div> <div style="width: 45%;"> <ul style="list-style-type: none"> • SIGN DIP SWITCH (page 117) • OVERHEAT FIX (page 119) </div> </div>

8.1.10 Problem: Only two LEDs in upper left are on

<p>SIGN APPEARANCE:</p>	
<p>POSSIBLE CAUSES:</p>	<ul style="list-style-type: none"> • The sign has overheated and turned off all but these two LEDs to protect itself from damage. For more information, see “3.5 Temperature protection” on page 21.
<p>SUGGESTED SOLUTIONS:</p>	<p>Follow the procedures listed below. Start on the left with “Messaging Computer Procedures” and work your way right to “Sign Procedures”:</p> <div style="text-align: center;">  </div> <ul style="list-style-type: none"> • OVERHEAT CHECK (page 118) • OVERHEAT FIX (page 119)

8.1.11 Problem: Text appears scrambled

<p>SIGN APPEARANCE:</p>	<p>Instead of this message appearing on the sign . . .</p>  <p>. . . scrambled text like one of the following appears:</p> <ol style="list-style-type: none"> 1  2  3  4  5 
<p>POSSIBLE CAUSES:</p>	<p>If the scrambled message looks <i>similar</i> to number:</p> <ul style="list-style-type: none"> • 1 = driver height set wrong (Bank 3 DIP switch #3). • 2 = sign length (columns) is set <i>longer</i> than the actual length of the sign (Bank 3 DIP switches #7 through 10). • 3 = sign length (columns) is set <i>shorter</i> than the actual length of the sign (Bank 3 DIP switches #7 through 10). • 4 = sign height (rows) is set <i>longer</i> than the actual height of the sign (Bank 3 DIP switches #4 through 6). • 5 = sign height (rows) is set <i>shorter</i> than the actual height of the sign (Bank 3 DIP switches #4 through 6).
<p>SUGGESTED SOLUTIONS:</p>	<p>Follow the procedures listed below. Start on the left with "Messaging Computer Procedures" and work your way right to "Sign Procedures":</p>  <ul style="list-style-type: none"> • PC DIP SWITCH (page 116) • SIGN DIP SWITCH (page 117)


8.1.12 Problem: Messages sent from AlphaNET software do not appear

SIGN APPEARANCE:	Messages from AlphaNET software do not appear on the sign(s).
POSSIBLE CAUSES:	<ul style="list-style-type: none"> • User error with AlphaNET software. • Messaging computer not set up properly. • AlphaNET software problem. • External power switch off. • Internal power switch off. • Cable and/or interface problem. • Sign malfunction (DIP switches misconfigured, sign overheating, sign damage, and so on).
SUGGESTED SOLUTIONS:	<p>Follow the procedures listed below. Start on the left with “Messaging Computer Procedures” and work your way right to “Sign Procedures”:</p> <div style="text-align: center; border: 1px solid black; padding: 5px; margin-bottom: 10px;"> </div> <ul style="list-style-type: none"> • PC-TO-SIGN check (page 79) • ALPHANETMESSAGE (page 82) • PC CHECK (page 84) • OUTSIDE INSPECTION (page 112) • SIGN RESTART (page 96) • INSIDE INSPECTION (page 113) • SIGN POWER (page 101) • SIGN FEEDBACK (page 99) • SIGN CHECK (page 104)


8.1.13 Problem: Graphics sent from AlphaNET software do not appear

SIGN APPEARANCE:	Graphics sent from AlphaNET software do not appear.
POSSIBLE CAUSES:	<ul style="list-style-type: none">• Graphic too large.• Wrong colors used in graphic• Graphic's "transparency" setting not turned off.
SUGGESTED SOLUTIONS:	See Creating Graphics for AlphaEclipse Signs (pn 9700-0130).


8.1.14 Problem: One or more LED boards is off

<p>SIGN APPEARANCE:</p>	
<p>POSSIBLE CAUSES:</p>	<ul style="list-style-type: none"> • Ribbon cable from previous LED board is not connected to the LED board that is out.
<p>SUGGESTED SOLUTIONS:</p>	<ul style="list-style-type: none"> • Follow the INSIDE INSPECTION procedure (page 113). • Make sure data and power cables are attached to the LED board(s) that are out. • Replace LED board if necessary (see "9.6 LED board replacement" on page 135).

8.1.15 Problem: Entire row of LED boards is off

<p>SIGN APPEARANCE:</p>	<p>Entire row of LED boards is out</p> 
<p>POSSIBLE CAUSES:</p>	<ul style="list-style-type: none"> • Ribbon cable from controller board is not connected to the first LED board in the row.
<p>SUGGESTED SOLUTIONS:</p>	<ul style="list-style-type: none"> • Follow the INSIDE INSPECTION procedure (page 113). • Make sure data and power cables are attached to the LED board(s) that are out. • Make sure that a ribbon cable for this row is connected to the controller board. • Replace LED board if necessary (see "9.6 LED board replacement" on page 135).

8.1.16 Problem: Entire section of sign is off

<p>SIGN APPEARANCE:</p>	<p>Entire section of LED sign is out</p> 
<p>POSSIBLE CAUSES:</p>	<ul style="list-style-type: none"> • Power supply for these LED boards has failed.
<p>SUGGESTED SOLUTIONS:</p>	<ul style="list-style-type: none"> • Follow the INSIDE INSPECTION procedure (page 113). • Make sure data and power cables are attached to the LED board(s) that are out. • Follow the SIGN POWER procedure (page 101). • Replace power supply if necessary (see “9.7 Power supply replacement” on page 137).

8.2 Troubleshooting procedures

Types of Troubleshooting Procedures





Figure 8: Types of troubleshooting procedures

8.2.1



PC-TO-SIGN CHECK procedure

Description:

- To see if communications exist between a sign and the messaging computer.
- To get information from the sign, such as its address, baud rate, and so on.




Figure 9: PC-TO-SIGN CHECK procedure flowchart (1 of 2)

8.2.1.1





Figure 10: PC-TO-SIGN CHECK procedure flowchart (2 of 2)

8.2.2



PC FEEDBACK procedure

Description:

- To see if there is one-way, two-way, or no communication between the messaging computer and the sign(s) that should receive messages from this computer.

NOTE: This procedure only works if the messaging computer uses one of the following communication interfaces: Converter Box III, modem, Zeus wireless transceiver, Locus radio modem, Lantronix MSS485-T, or an interface that has separate transmit and receive indicators.





Figure 11: PC FEEDBACK procedure flowchart

8.2.3



ALPHANET MESSAGE procedure

Description:

- To see if a message created using AlphaNET software and simulated on a computer screen, looks the same on an actual sign.

NOTE: This procedure erases all messages currently stored in a sign.




Figure 12: ALPHANET MESSAGE procedure flowchart (1 of 2)

8.2.3.1





Figure 13: ALPHANET MESSAGE procedure flowchart (2 of 2)

8.2.4



Description:

- To determine if there is a fault in the messaging computer's cables and/or interfaces (modem, wireless transceiver, and so on).




Figure 14: PC CABLE CHECK procedure flowchart

8.2.4.1



PC CHECK-RS232 procedure

Description:

- To determine if the messaging computer's settings and RS232 cable are working correctly.





Figure 15: PC CHECK-RS232 procedure flowchart

8.2.4.2



Description:

- To see if there is communication between the messaging computer and the Converter Box III.




Figure 16: PC CHECK-RS485 procedure flowchart

8.2.4.3



PC CHECK-FIBER procedure

Description:

- To see if the fiber optic modem connected to the messaging computer has power and is set up properly.





Figure 17: PC CHECK-FIBER procedure flowchart

8.2.4.4



Description:

- To see if there is communication between the messaging computer and a modem.



Go to **PC CHECK-MODEM-1** on page 89.

Figure 18: PC CHECK-MODEM procedure flowchart (1 of 2)

8.2.4.4.1





Figure 19: PC CHECK-MODEM procedure flowchart (2 of 2)

8.2.4.5

Messaging Computer
procedureCables and Interfaces
procedureSign
procedure**PC CHECK-WIRELESS procedure**

Description:

- To see if there is communication between the messaging computer and a wireless transceiver.





Figure 20: PC CHECK-WIRELESS procedure flowchart

8.2.4.6



Description:

- To see if there is communication between the messaging computer and an IR Message Loader.






Figure 21: PC CHECK-IRLOADER procedure flowchart (2 of 2)

8.2.4.7



PC CHECK-ETHERNET procedure

Description:

- To see if there is communication between the messaging computer and a Lantronix MS485-T serial server.




Figure 22: PC CHECK-ETHERNET procedure flowchart (1 of 3)

8.2.4.7.1 **PC CHECK-ETHERNET-1 procedure**




Figure 23: PC CHECK-ETHERNET procedure flowchart (2 of 3)

8.2.4.7.2





Figure 24: PC CHECK-ETHERNET procedure flowchart (3 of 3)

8.2.5

Messaging Computer procedure Cables and Interfaces procedure **Sign procedure** **SIGN RESTART procedure**

Description:

- To get information from the sign like its address, baud rate, and so on by cycling the sign's power.





Figure 25: SIGN RESTART procedure flowchart

8.2.6




TEST MODES procedure

Description:

- To determine if a sign is locked into one of the following test modes (test mode names taken from AlphaNET Diagnostics software).
 - Test Pattern Mode — diagonal lines and blocks keep repeating on the sign.
 - Test Match Mode — all LEDs are on.
 - Production Test Mode — sign starts up filled with letter “B”s. Then a series of letters and numbers appear on the far right side of the sign.
 - Temperature Test Mode — the temperature is displayed on the far right side of the sign. If a temperature probe is not connected to the sign, then the letters “ERR” will appear instead of the temperature.
- To set the sign to normal operating mode.

Table 21: Test Mode information

<p>Test Mode</p> <p>(These are the names used in AlphaNET Diagnostics software.)</p>	<p>DIP switch settings</p>	<p>Does the sign display the Diagnostics software Broadcast Message?</p>	<p>Can the sign be reset to normal operation using the Diagnostics software?</p> <p><i>Configure Sign (Advanced) > Initiate Test Mode > Run Normally</i></p>	<p>Do controller board LEDs blink during Broadcast Message?</p> 
<p>Test Pattern</p>	<p>Bank 2: #10 = OFF, #9 = ON Bank 1: n/a</p>	<p>Yes</p>	<p>Yes</p> <p>(The message “DIP DISABLED” will appear each time the sign is restarted.)</p>	<p>Yes</p>
<p>Test Match Mode</p>	<p>Bank 2: #10 = ON, #9 = OFF Bank 1: n/a</p>			
<p>Production Test Mode</p>	<p>Bank 2: n/a Bank 1: #9 = OFF, #8 = ON</p>			
<p>Temperature Test Mode</p>	<p>Bank 2: n/a Bank 1: #9 = ON, #8 = OFF</p>			




Figure 26: TEST MODES procedure flowchart

8.2.7

**SIGN FEEDBACK procedure**


Description:

- To see if there is one-way, two-way, or no communication between the messaging computer and the sign.

**SIGN FEEDBACK**

In the AlphaNET Diagnostics software:


1. Click *Actions > Continuous Read Temperature*.
2. Click *Select*.
3. Click *Internal Temperature*.
4. Set *How Often to Read Temperature* to *15 seconds* (as short as possible).
5. Click *Start*.
6. Click *Select Address*.
7. If you do not know the sign's address, click *All Addresses*. Otherwise, click *Selected Addresses* and if it is not already there, add the sign's address to the *Address List*.
8. Click *OK*.
9. Click *Start* to begin reading sign temperatures.
10. Watch the communication LEDs (shown below) on the sign's controller board. Each time the Diagnostic software requests a sign to send the temperature, the communication LEDs should briefly blink.



Go to **SIGN FEEDBACK-1** on page 100.

Figure 27: SIGN FEEDBACK procedure flowchart (1 of 2)

8.2.7.1



SIGN FEEDBACK-1 procedure




Figure 28: SIGN FEEDBACK procedure flowchart (2 of 2)

8.2.8

Messaging Computer procedure
Cables and Interfaces procedure
Sign procedure

SIGN POWER procedure

Description:

- To see if power is supplied to the sign and its components (controller board, power supplies, and so on).




Figure 29: SIGN POWER procedure flowchart (1 of 3)

8.2.8.1




Figure 30: SIGN POWER procedure flowchart (2 of 3)

8.2.8.2




Figure 31: SIGN POWER procedure flowchart (3 of 3)

8.2.9

**SIGN CHECK procedure**

Description:

- To determine if there is a fault in the sign's cables and/or interfaces (modem, wireless transceiver, and so on).





Figure 32: SIGN CHECK procedure flowchart

8.2.9.1



SIGN CHECK-RS232 procedure

Description:

- To determine if the sign’s RS232 cabling is working correctly.




Figure 33: SIGN CHECK-RS232 procedure flowchart

8.2.9.2



Description:

- To determine if the sign's RS485 cabling is working correctly.





Figure 34: SIGN CHECK-RS485 procedure flowchart

8.2.9.3



SIGN CHECK-FIBER procedure

Description:

- To determine if the sign’s fiber optic modem and cabling are working correctly.




Figure 35: SIGN CHECK-FIBER procedure flowchart

8.2.9.4

**SIGN CHECK-MODEM procedure**

Description:

- To determine if the sign's modem and cabling are working correctly.





Figure 36: SIGN CHECK-MODEM procedure flowchart

8.2.9.5



SIGN CHECK-WIRELESS procedure

Description:

- To determine if the sign’s wireless transceiver and cabling are working correctly.




Figure 37: SIGN CHECK-WIRELESS procedure flowchart

8.2.9.6

Messaging Computer
procedureCables and Interfaces
procedureSign
procedure**SIGN CHECK-IRLOADER procedure**

Description:

- To determine if the sign's external connection box for an IR Message Loader is working correctly.





Figure 38: SIGN CHECK-IRLOADER procedure flowchart

8.2.9.7



SIGN CHECK-ETHERNET procedure

Description:

- To determine if the sign's RS485 connection to a MSS485-T is working correctly.





Figure 39: SIGN CHECK-ETHERNET procedure flowchart

8.2.10

**OUTSIDE INSPECTION procedure**

Description:

- To see if there are any external, visual indications of damage to the sign(s).




Figure 40: OUTSIDE INSPECTION procedure flowchart

8.2.11

Messaging Computer
procedureCables and Interfaces
procedureSign
procedure**INSIDE INSPECTION procedure**

Description:

- To see if there are any internal, visual indications of damage to the sign(s).






Figure 41: INSIDE INSPECTION procedure flowchart

8.2.12

**TEMP PROBE CHECK procedure**

Description:

- To see if a temperature probe is operating correctly.




Figure 42: TEMP PROBE CHECK procedure flowchart

8.2.13

Messaging Computer procedure
Cables and Interfaces procedure
Sign procedure

TEMP PROBE FIX procedure

Description:

- To correct a faulty temperature probe.





Figure 43: TEMP PROBE FIX procedure flowchart

8.2.14

**PC DIP SWITCH procedure**

Description:

- To use AlphaNET software to change one or more DIP switches on a sign's controller board.




Figure 44: PC DIP SWITCH procedure flowchart

8.2.15

Messaging Computer
procedureCables and Interfaces
procedureSign
procedure**SIGN DIP SWITCH procedure**

Description:

- To physically change one or more DIP switches on a sign's controller board.





Figure 45: SIGN DIP SWITCH procedure flowchart

8.2.16

**OVERHEAT CHECK procedure**

Description:

- To see if a sign is overheating




Figure 46: OVERHEAT CHECK procedure flowchart

8.2.17

Messaging Computer procedure
Cables and Interfaces procedure
Sign procedure

OVERHEAT FIX procedure

Description:

- To try to fix a sign that is overheating




Figure 47: OVERHEAT FIX procedure flowchart

8.3 Controller board DIP switches

Three banks of DIP switches, located on the controller board (below), control much of the sign's operation.

However, there are differences in how DIP switches function in Series A and B signs.




Figure 48: Controller board DIP switch location (Series A and B)

8.3.1 Bank 1 and Bank 2 DIP switches

* indicates that this DIP switch setting can be set using AlphaNET Diagnostics software.

Controller board (side view)

Bank 2 DIP switches

	10	9	Description
Diagnostics	Off	Off	Normal messaging (default)
	Off	On	Test Pattern Mode — Repeating diagonal lines and blocks to test for LED outages.
	On	Off	Test Match Mode — All LEDs are lit to test for uniform LED display
	On	On	Software override — When switches #10 and #9 are both on <i>and</i> Bank 1 DIP switches #9 and #8 are also on, then the sign will use the current DIP switch settings. Also, AlphaNET Diagnostics software will <i>not</i> be able to override any DIP switch settings.

	8	Description
Data format	Off	8N1 — 8 data bits, No parity, 1 stop bit (default)
	On	7E2 — 7 data bits, Even parity, 2 stop bits

	7 (MSB)	6	5	4	3	2	1 (LSB)	Address		
								Dec	Hex	
Serial address (address 0 = default)	Off	Off	Off	Off	Off	Off	Off	0	00	
	Off	Off	Off	Off	Off	Off	On	1	01	
	Off	Off	Off	Off	Off	On	Off	2	02	
	Off	Off	Off	Off	Off	On	On	3	03	

	On	On	On	On	On	Off	On	125	7D	
On	On	On	On	On	On	Off	126	7E		
On	On	On	On	On	On	On	127	7F		

Bank 1 DIP switches

	10	Description
Memory clear	Off	Do NOT clear memory on sign startup (default)
	On	Clear memory on sign startup

	9	8	Description
Test modes	Off	Off	Normal mode (default)
	Off	On	Production Test Mode — Sign starts filled with letter “B”s.
	On	Off	Temperature Test Mode — The temperature is displayed on the far left of the sign.
	On	On	Software override — see the “Software override” explanation for Bank 2 DIP switches #10 and #9

	7	Description
Master/Slave	Off	Master mode (default)
	On	Slave mode


	5	4	3	Description
Baud rate	Off	Off	Off	Autobaud (see below)
	Off	Off	On	1200
	Off	On	Off	2400
	Off	On	On	4800
	On	Off	Off	9600
	On	Off	On	19200
	On	On	Off	38400
On	On	On	Autobaud (see below)	

When Autobaud is on, the sign will try to set the sign to the baud rate and data format of the transmitting device, like a modem. *Make sure that Data format (Bank 2, switch #8) is off.*



	2	1	Description
RS485 Termination	Off	Off	Termination off (default)
	On	On	Termination on

8.3.2 Bank 3 DIP switches

Controller board (back view):



* indicates that this DIP switch setting can be set using AlphaNET Diagnostics software.



Example: How to calculate Sign height and Sign length:

Sign size is typically represented in pixels, as in 160 (columns) x 24 (rows). This means the sign is 160 pixels long and 24 pixels high. In AlphaEclipse 3500 signs, each line is 8 pixels high. So a 160 x 24 sign has a Sign height = 3 (24/8) and a Sign length = 160.

Bank 3 DIP switches

Sign length (columns)				Description
10	9	8	7	
Off	Off	Off	Off	64 columns (default)
Off	Off	Off	On	16 columns
Off	Off	On	Off	32 columns
Off	Off	On	On	48 columns
Off	On	Off	Off	64 columns
Off	On	Off	On	80 columns
Off	On	On	Off	96 columns
Off	On	On	On	112 columns
On	Off	Off	Off	128 columns
On	Off	Off	On	144 columns
On	Off	On	Off	160 columns
On	Off	On	On	176 columns
On	On	Off	Off	192 columns
On	On	Off	On	208 columns
On	On	On	Off	224 columns
On	On	On	On	240 columns

Sign height (lines)				Description
6	5	4		
Off	Off	Off		1 line (default)
Off	Off	On		2 lines
Off	On	Off		3 lines
Off	On	On		4 lines
On	Off	Off		5 lines
On	Off	On		6 lines
On	On	Off		7 lines
On	On	On		8 lines
				Not valid for 3500 signs


Driver board height	
3	Description
Off	8-row high (default)
On	16-row high

8.4 AlphaNET Diagnostics software

This applies to Diagnostics software version 3.0.113.

8.4.1 Startup screen

Table 22: Startup screen




Item	Name	Description	
A	Communications	<ul style="list-style-type: none"> Serial/Wireless <ul style="list-style-type: none"> Sets the COM port, baud rate, and data format for either RS232/RS485 wired or wireless transceiver sign connections. Auto detects the sign using the information entered above. <i>Only detects a sign with address 01.</i> Modem <ul style="list-style-type: none"> Sets the COM port, baud rate, data format, dialing prefix, initialization string, number to dial, timeout, and configuration string. Configures modem using the information entered above. TCP/IP <ul style="list-style-type: none"> Sets the IP address and port for the Ethernet interface (Lantronix MSS485-T) connected to the sign. Pings the IP address entered above. 	
	B	Actions	<ul style="list-style-type: none"> Connect to Modem <ul style="list-style-type: none"> Only appears if <i>Communications > Modem</i> is selected. Disconnect Modem <ul style="list-style-type: none"> Only appears if <i>Communications > Modem</i> and <i>Connect to Modem</i> were selected. Read Information from Sign <ul style="list-style-type: none"> Displays sign information like firmware revision, lists of sign files, serial error register status, temperature, and so on.

Table 22: Startup screen

B	<i>Actions</i>	<i>Configure Sign</i>	<ul style="list-style-type: none"> For all signs, sets the date, time, and serial address. If power is removed from a sign, on power up a sign will use its previous serial address. For outdoor signs (like the AlphaEclipse 3500), sets dimming time and level, and temperature offset.
		<i>Configure Sign (Advanced)</i>	<ul style="list-style-type: none"> Sets sign size (columns and rows), serial address, test modes, baud rate and data format, and other sign options. Returns sign to its DIP switch settings by selecting <i>Reset to DIP Configuration</i>. Works for all AlphaEclipse Series B signs, but only AlphaEclipse Series A signs that have revision G or later firmware installed.
		<i>Continuous Temperature Read</i>	<ul style="list-style-type: none"> Continuously displays a sign's internal temperature or the temperature from a temperature probe that is connected to the sign.
		<i>Broadcast Message</i>	<ul style="list-style-type: none"> Sends a message to all signs, selected sign addresses, or continuously.
		<i>Clear Memory</i>	<ul style="list-style-type: none"> Erases all messages from one or more signs. Restarts the sign(s).
		<i>Reset Sign</i>	<ul style="list-style-type: none"> Restarts one or more signs.
		<i>Network Query</i>	<ul style="list-style-type: none"> Identifies one or more signs.
		<i>Beep</i>	not applicable to AlphaEclipse signs
		<i>Lamp Test</i>	<ul style="list-style-type: none"> Indicates which LEDs have burned out on one or more signs.

8.4.2 Configure Sign (Advanced) screen

Table 23: Configure Sign (Advanced) screen



Item	Name	Controller board DIP switch(es)	Notes
A	Set Sign Serial Data Format	Autobaud	Bank 2, switch #8 (data format) Bank 1, switches #5, #4, and #3 (baud rate)
		1200 (8N1)	
		1200 (7E2)	
		...	
		38400 (7E2)	
B	Initiate Test Mode	Run Normally	Bank 2, switches #10 and #9 Bank 1, switches #9 and #8
		Production Test Mode	
		Test Pattern	
		Test Match Mode	
		Temperature Test Mode	
C	Set Serial Address	00 through FF (hexadecimal)	Bank 2, switches #7, #6, #5, #4, #3, #2, #1 Unlike <i>Configure Sign > Change Sign Address</i> , address changes made with <i>Set Serial Address</i> will not change when power is removed from a sign.
D	Set Sign Size	Column Size	Bank 3, switches #10, #9, #8, and #7
		Row Size	Bank 3, switches #6, #5, and #4
E	Set Other Options	Clear Memory on Power Up?	Bank 1, switch #10
		Master/Slave	Bank 1, switch #7
		Demo Message	not applicable
		Color	
		IR	
		RS485 Echo	
		Driver Height	Bank 3, switch #3
F	Reset to DIP Configuration		

9.0 Parts replacement

9.1 List of field-replaceable parts

Table 24: Field-replaceable parts

Part name	Series B sign
Controller board	Yes (page 130)
Turbo Extender board	Yes (page 131)
Exhaust fan	Yes (page 132)
Power supply fan	Yes (page 134)
LED board	Yes (page 135)
Power supply	Yes (page 137)

9.2 Controlling electrostatic discharge (ESD)



This equipment contains components that may be damaged by “static electricity”, or electrostatic discharge. To prevent this from happening, be sure to follow the guidelines in Adaptive Tech Memo 00-0005, “*Guidelines for Controlling Electrostatic Discharge Damage*”, available at Adaptive’s web site at <http://www.adaptivedisplays.com>.

9.3 Controller board

9.3.1 Controller board description

Table 25: Series B controller board description








<p><u>Top view</u></p>  <p><u>Side view:</u></p>  <p><u>Back view:</u></p> 		
Item	Name	Description
A	Diagnostic LEDs	<p>The top two LEDs are not used. The bottom two LEDs are used as follows:</p>  <ul style="list-style-type: none"> Top two LEDs are not functional. Blue LED — blinks once per second = ok. Steady or off = error. Green LED — lit during FLASH memory upload.

Table 25: Series B controller board description

B	Serial port	<p>Communication LEDs</p>  <p>SERIAL PORT</p> <ul style="list-style-type: none"> +5V 1 GND 2 RS232 RXD 3 RS232 TXD 4 SHIELD 5 RS485 - 6 RS485 + 7 <p>Serial board</p>
C	Communication LEDs	<p>Red LEDs = incoming data (Rx), Green LEDs = outgoing data (Tx):</p>  <p>RS232 RS485</p>
D	Serial board	See <i>Serial port</i> above.
E	Photocell connector	Sign's photocell connects here.
F	FPGA chip (socketed)	Controls sign operations.
G	LED row 1 connector	Signal cable for LED row 1 on the sign.
H	Temperature probe connector	Series B temperature probe connects here.
I	LED row 2 connector	Signal cable for LED row 2 on the sign.
J	LED row 3 connector	Signal cable for LED row 3 on the sign.
K	LED row 4 connector	Signal cable for LED row 4 on the sign.
L	Turbo extender board	<p>Supplies data to each LED row in the sign.</p>  <p>TEMP/SYNC PORT</p> <ul style="list-style-type: none"> 1 RS485B (-) 2 RS485A (+) 3 SHIELD 4 GND 5 VCC
M	Main FLASH firmware chip (socketed)	Controls sign operations.
N	Bank 3 DIP switches	Controls sign operations. See "8.3.2 Bank 3 DIP switches" on page 122.
O	Bank 2 DIP switches	Controls sign operations. See "8.3.1 Bank 1 and Bank 2 DIP switches" on page 121.
P	Bank 1 DIP switches	


9.3.2 Controller board replacement

NOTE: Do NOT attempt this procedure if there are strong winds or if it is raining or snowing.

1 Open the sign.

- Follow the steps in “4.2.2 Opening the sign” on page 31.

2 Detach all cables from the controller board.



3 Remove the controller board from the sign.



Remove the four screws that are circled.

4 Install the replacement controller board.

- Make sure that the DIP switches on the replacement controller board match those on the controller board being replaced. (See “8.3 Controller board DIP switches” on page 120.)

5 Close the sign.

- Follow the steps in “4.2.5 Closing the sign” on page 35.


9.4 Turbo extender board replacement

The Series B sign has only one type of turbo extender board. This board is attached to the controller board and is similar in function to a Series A sign Master Turbo Extender board..


1 Open the sign.

- ❑ Follow the steps in “4.2.2 Opening the sign” on page 31.

2 Detach all cables from the turbo extender board.



3 Remove the turbo extender board from the controller board.



4 Attach the replacement turbo extender board to the controller board.

5 Close the sign.

- ❑ Follow the steps in “4.2.5 Closing the sign” on page 35.

9.5 Fan replacement

There are two types of fans in a sign. Both types are powered by line (120/240V) voltage:

- Exhaust fan — moves air *into* and *out* of a sign and only turn on when the sign reaches a designated temperature (see “3.5 Temperature protection” on page 21). Exhaust fans are larger than the power supply fans. Exhaust fans either blow air into or out of a sign. Exhaust fans that blow air *into* a sign should be covered with a plastic cover inside a sign.

NOTE: In Series B signs, the FAN TEST button, located on the sign’s internal power switch, can be used to temporarily turn the exhaust fans on.

- Power supply fan — moves air *inside* a sign. *When a sign has power, power supply fans should be on.*

9.5.1 Exhaust fan replacement

1 Open the sign.

- Follow the steps in “4.2.2 Opening the sign” on page 31.

2 If the exhaust fan has a plastic cover, remove it.



Remove the circled screws and standoffs.

Fan power cable (120/240V)

3 Detach the fan power cable. Then remove the fan from the sign.

Remove the circled screws.

Detach the fan power cable (120/240V).



4 Install the replacement exhaust fan.

- If there was a plastic cover on the original fan, install it over the replacement fan.

5 Close the sign.


- Follow the steps in "4.2.5 Closing the sign" on page 35.

9.5.2 Power supply fan replacement

1 Open the sign.

- Follow the steps in “4.2.2 Opening the sign” on page 31.

2 Disconnect the fan power cable from the 120/240V connection terminal. Then remove the screws that hold the fan to the sign.



3 Remove the screws that hold the fan to the mounting bracket.



4 Install the replacement power supply fan.

5 Close the sign.

- Follow the steps in “4.2.5 Closing the sign” on page 35.


9.6 LED board replacement

NOTE: The *replacement* LED board should have the same BIN letter as the current LED board.


1 Open the sign.

- ☐ Follow the steps in “4.2.2 Opening the sign” on page 31.

2 Remove the 5V power and data cables attached to the back of the LED board.



3 Lower all the LED boards.

4 Remove the screws that attach the LED board to the sign.LED board (back)

Remove the circled screws.

5 Install the replacement LED board.

- The replacement LED board should have the same BIN letter as the original board.
- Locate the text "TOP" on the LED board. Install the board with this text facing up.

6 Close the sign.

- Follow the steps in "4.2.5 Closing the sign" on page 35.

9.7 Power supply replacement

9.7.1 Power supply description

The Meanwell SP-200-5 power supply used in this sign provides 5V power to the LED boards:

Table 26: Meanwell SP-200-5 power supply description

Item	Name	Description
A		Power LED (green) — when lit, indicates that the power supply is functioning.
B	+V	5 VDC output to LED boards.
C	-V	
D	FG (or ground symbol)	Ground connector.
E	N (neutral)	100-240 VAC input.
F	L (line voltage)	


9.7.2 Power supply replacement

1 Open the sign.

- ❑ Follow the steps in “4.2.2 Opening the sign” on page 33.

2 Disconnect the 5V and line voltage wires from the power supply.

- ❑ If there is a ground jumper (shown below), then remove it and use it on the replacement power supply.



3 Remove the power supply from the sign.



Remove the circled screws.

4 Install the replacement power supply.

- Fasten the replacement power supply to the sign.
- Connect the 5V and line voltage wires to the power supply.
- If there was a ground jumper on the original power supply, then install it on the replacement unit.

5 Close the sign.

- Follow the steps in “4.2.5 Closing the sign” on page 37.

9.8 Firmware upgrade

This information is contained in the latest revision of Adaptive TechMemo #01-0010 (go to <http://www.adaptivedisplays.com/ams/dtechmemo.htm>).