

PRIORITY:	High
DATE:	January 3, 2007
TITLE:	Swapping Board Level Components on Outdoor Signs
ECO REFERENCE:	n/a
PRODUCT(S) AFFECTED:	AlphaEclipse 3600, Excite, Infinity, RoadStar, and StreetSmart signs.
SUMMARY:	Board level components are not to be hot-swapped. Follow these instructions to swap board level components.

Overview

Hot-swapping board level sign components can cause failures. These failures may occur immediately, be intermittent, or may show no symptoms until later.

Only swap board level components with the power to the sign disconnected and follow the instructions in this document. If you need to troubleshoot components, contact Adaptive Micro Systems Technical Services at 414-357-2020 extension 519 during business hours.

Replacing Board Level Sign Components

WARNING! Hazardous voltage. Contact with high voltage may cause death or serious injury. Always disconnect power to unit prior to servicing.

Preventing electrostatic discharge damage

Signs contain components that may be damaged by static electricity or electrostatic discharge. To prevent this from happening, follow the guidelines in Adaptive Tech Memo 00-0005, "[Preventing Electrostatic Discharge \(ESD\) Damage](#)."

To swap board level components:

1. Disconnect power from the sign. Disconnecting power on a row or section is insufficient, you must disconnect power from the entire sign.
2. Remove the component:
 - Disconnect the data connection(s) to the board first.
 - Disconnect the power to the board last.
3. Install the component:
 - Connect the power to the board first.
 - Connect the data connection(s) last.

© Copyright 2007 Adaptive Micro Systems LLC. All rights reserved.

Adaptive Micro Systems • 7840 North 86th Street • Milwaukee, WI 53224 USA • 414-357-2020 • 414-357-2029 (fax) • <http://www.adaptivedisplays.com>

Trademarked names appear throughout this document. Rather than list the names and entities that own the trademarks or insert a trademark symbol with each mention of the trademarked name, the publisher states that it is using names for editorial purposes and to the benefit of the trademark owner with no intention of improperly using the trademark.

The following are trademarks of Adaptive Micro Systems: Adaptive, Alpha, AlphaLert, AlphaNET, AlphaNet plus, AlphaEclipse, AlphaEclipse RoadStar, AlphaEclipse StreetSmart, AlphaPremiere, AlphaTicker, AlphaVision, AlphaVision InfoTracker, Automode, BetaBrite, BetaBrite Director, BetaBrite Messaging Software, Big Dot, Director, EZ KEY II, EZ95, PagerNET, PPD, PrintPak, Serial Clock, Smart Alec, Solar, TimeNet.

The distinctive trade dress of this product is a trademark claimed by Adaptive Micro Systems LLC.

Due to continuing product innovation, specifications in this manual are subject to change without notice.